Installation and Wiring of HT20-50W Systems

Simple installation steps of connecting panel cables to Luminaire:

Steps

1. Install and secure arm to Wall
2. Connect both MC4 connectors of Luminaire (Cable A) to matching connectors of Cable B
3. Turn ON Luminaire by pressing 0N-OFF Push Button
   Wait 60 seconds for the light to turn ON
4. Connect Panel Cable C to Extension Cable

5. Wait 30 seconds for the light to turn OFF

INSTALLATION COMPLETE

Solar Panel Cables

Extension Cables 2m long

Extension Cables 2m long

Cable A

Cable A

MC4 quick connect, polarity specific

ON-OFF PB