

VPHB1SERIES VAPOR PROOF HIGH BAY FIXTURE

INSTALLATION INSTRUCTIONS



For use with:

Model #	Input Voltage	Wattage
VPHB1-41504-3	120-347V	150W

WHAT'S IN THE BOX

- LED FIXTURE
- MOUNTING CLIPS

WHAT YOU'LL NEED

- SAFETY GLASSES
- WIRE CUTTERS
- WIRING SUPPLIES AS SPECIFIED BY CODE

WARNING

- Turn off electrical power at fuse or circuit breaker box before wiring fixture to the power supply.
- Turn off the power when you perform any maintenance.
- Verify that supply voltage is correct by comparing it with the luminaire label information.
- Keep lens tightly closed when in operation.
- Modifications to the product voids the warranty.

IMPORTANT

Before assembling your PREMISE LED fixture, please make sure that you carefully read through this instruction sheet. Consider having your fixture installed by a qualified licensed electrician.

Note: The important safeguards and instructions that appear in this sheet are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care are factors that cannot be built into any product. These factors must be supplied by the person(s) caring for and operating the fixture.

PREMISE LED Inc.

80-86 Carrier Drive Toronto, ON Canada M9W 5R1

PREMISELED.COM

TO INSTALL THE FIXTURE

- Drill the pilot holes and mount the two ceiling brackets directly to the ceiling using suitable anchors and screws.
- 2. Secure the back of the fixture housing to the mounting brackets.
- Ensure that the LED tray is secure by installing the safety tethers. This allows the LED tray to hang down from the tray bracket for connections and servicing.
- 4. Make the appropriate wiring connections by referring to the wiring diagram provided. Ensure that the unused knockout on the other side of the fixture is sealed with the supplied plug.
- 5. Close the LED tray and secure it back onto the housing by snapping it in place.
- 6. Reattach the lens cover and secure it using the steel latches.
- 7. Installation is now complete.









